

HOBO ZW Series is a family of wireless data nodes that provide centralized monitoring of energy and environmental conditions in buildings.

Best suited for on-site facility monitoring applications where web-based data access is not required, HOBO data nodes transmit high-accuracy, real-time data from dozens of points to a central PC. This eliminates the need of having to manually retrieve and offload individual data loggers, saving you time and money.

#### Measurements:

Temperature
Relative humidity
AC voltage
AC current
Kilowatts
Kilowatt hours
Gauge pressure
CO<sub>2</sub>

Compressed airflow DC current Differential pressure Water usage 4-20 mA 0-10 vdc Pulse

### **Key Advantages:**


- Provides centralized building performance data collection
- Transmission of real-time data within a self-healing mesh network eliminates line-of-sight issues
- Automatically routes data back to receiver
- Onboard buffer memory helps prevent data loss
- Alarm notification via email or text messages
- Powerful software for organizing and viewing data
- Map deployed data nodes
- Label and group data nodes for easy identification

#### **Centralized Data Collection**


HOBO data nodes, routers, and receivers all work together as a system to provide reliable, accurate real-time information on how a building is performing. Whether you are a warehouse manager looking to keep a close eye on temperature and humidity conditions, a facility manager looking at indoor air quality, or a building energy manager tracking energy use, HOBO data nodes provide reliable data collection without the hassles of manually offloading data.

### **Self-Healing Technology**

HOBO data nodes leverage MESH networking technology, which ensures that data is automatically re-routed back to the receiver without any manual intervention.



Scenario 1. Typical data flow back to the receiver



Scenario 2. Self healing network automatically compensates for new obstruction





#### **Advanced Software Capabilities**

HOBOnode™ Manager software, a component of HOBOware Pro graphing and analysis software, lets you view real-time energy and environmental data, set alarm notifications, and get an at-a-glance view of your network with the Network Map feature. HOBOnode Manager software also offers one-click export of your data to Microsoft Excel and other programs, and provides network signal strength indication.


HOBOware Pro 3.0 is included with the ZW Receiver

### **Alarm Capabilities:**

- HOBOnode Manager software will send a text message to your phone and email your computer when conditions exceed set thresholds.
- System alarms lets you know if a data node is not connected to your network.

### **Network Map Feature**

In many monitoring applications, it's important to view a complete network of your HOBO Data Nodes. HOBOnode Manager's Network Map feature provides an at-a-glance view of your network so you can easily locate your HOBO Data Nodes within a building.



HOBOnode manager's Network Map feature provides at-a-glance view of a HOBO data node network.





Specifications								
	ZW-RCVR (Receiver)	ZW-001	ZW-003	International State of the Stat	ZW-006	EMP Arterior Laborator Lab	ZW-008	ZW-ROUTER (Router)
Measurements	N/A	Temp	Temp, RH	External T/RH, 1 analog port, 1 pulse input port	4 external analog ports	External T/RH, 2 analog ports	2 analog ports, 2 pulse input ports	N/A
Probe Size				1cm (0.38 in) diameter probe on 1.8 m (6ft cable)		1cm (0.38 in) diameter probe on 1.8 m (6ft cable)		
Buffer memory	up to 95k measurements	5k measurements	4k measurements	3k measurements	3k measurements	3k measurements	3k measurements	N/A
Sample rate	N/A	1 min to 18 hrs	1 min to 18 hrs	1 min to 18 hrs	1 min to 18 hrs	1 min to 18 hrs	1 min to 18 hrs	N/A
Transmission rate	N/A	2 min and greater	2 min and greater	2 min and greater	2 min and greater	2 min and greater	2 min and greater	N/A
Power options	AC power adapter, USB, Battery	AC power adapter, Battery Backup	AC power adapter, Battery Backup	AC power adapter, Battery Backup	AC power adapter, Battery Backup	AC power adapter, Battery Backup	AC power adapter, Battery Backup	AC power adapter, Battery Backup
Measurement range	N/A	Temp: -40° to 70° C (-40° to 158° F)	Temp: -40° to 70° C (-40° to 158° F) RH: 5 to 95% RH	Temp: -40° to 70° C (-40° to 158° F) RH: 5 to 95% RH Analog channels: 0 to 2.5 Vdc; 0 to 5 Vdc (W/CABLE-ADAP5); 0 to 10 Vdc (W/ CABLE-ADAP10) 4-20 mA Pulse channel: 0 to 65,535 pulses per logging interval	Analog channels: 0 to 2.5 Vdc; 0 to 5 Vdc (wCABLE-ADAP5); 0 to 10 Vdc (w/ CABLE-ADAP10)	Temp: -40° to 70° C (-40° to 158° F) RH: 5 to 95% RH Analog channels: 0 to 2.5 Vdc; 0 to 5 Vdc (w/ CABLE- ADAP5); 0 to 10 Vdc (w/ CABLE- ADAP10).	Analog channels: 0 to 2.5 Vdc; 0 to 5 Vdc (w/ CABLE- ADAP5); 0 to 10 Vdc (w/ CABLE- ADAP10). 4-20 mA Pulse channel: 0 to 65,535 pulses per logging interval	N/A
Accuracy	N/A	Temp: ± 0.2° C over 0° to 50° C (± 0.36° F over 32° C to 122° F)	Temp: ± 0.2° C over 0° to 50° C (± 0.36° F over 32° to 122° F) RH: ± 2.5% from 10 to 90% typical, max. ± 3.5%	Temp: ±0.2° C over 0° to 50° C (±0.36° F over 32° to 122° F) RH: ±2.5% from 10 to 90% typical, max. ±3.5% Analog: ±1.544 mV plus 2 % of reading (typical)	Analog: ± 1.544 mV plus 2% of reading (typical)	Temp: ± 0.2° C over 0° to 50° C (± 0.36° F over 32° to 122° F) RH: ± 2.5% from 10 to 90% typical, max. ± 3.5% Analog: ± 1.544 mV plus 2 % of reading (typical)	Analog: ± 1.544 mV plus 2% of reading (typical)	N/A
Resolution	N/A	Temp: 0.02° C @ 25° C (0.04° F @ 77° F)	Temp: 0.02° C @ 25° C (0.04° F @77° F) RH: 0.03%	Temp: 0.02° C @ 25° C (0.04° F @77° F) RH: 0.03% Analog channel: 0.6 mV Pulse Channel: 1 pulse	Analog channel: 0.6mV	Temp: 0.02° C @ 25° C (0.04° F @77° F) RH: 0.03% Analog channel: 0.6 mV	Analog channel: 0.6mV Pulse Channel: 1 pulse	N/A
Response time	N/A	Temp: 5 min. in air moving 1 m/s (3.3 ft/sec)	Temp: 5 min. in air moving 1 m/s (3.3 ft/sec) RH: 10 min. in air moving 1 m/s (3.3 ft/sec)	Temp: 5 min. in air moving 1m/s (3.3 ft./sec) RH: 10 min. in air moving 1 m/s (3.3ft/ sec)	Dependent on sensor	Temp: 5 min. in air moving 1m/s (3.3 ft./sec) RH: 10 min. in air moving 1 m/s (3.3ft/sec)	Dependent on sensor	N/A

A base system requires a HOBO Data Node, Receiver, and HOBOware Pro software\*

Common **Specifications** 

Approx. 100 m (300ft.) depending on obstructions or interference 138 g (4.87 oz) with batteries 96.5 x 108 x 28 mm (3.8 x 4.25x 1.1 in) Range: Weight: Size:

Radio Power: 1.6 mW (2 dBm) Wireless data

Standard: IEEE 802.15.4 2.4 GHz band

For more detailed specifications, please refer to individual device manuals FCC Certified. Check www.onsetcomp.com for the latest certification.

\* HOBOware Pro is included with the cost of the ZW Receiver.

\*\*External T/RH cables included





## **Ordering Information**

Data Loggers		Compressed Air Flow Meter**	
Receiver & HOBOware Pro Software	ZW-RCVR	1-80 SCFM	T-CDI-5200-10S
Router only	ZW-ROUTER	3-350 SCFM	T-CDI-5400-20S
Integrated Temperature	ZW-001	Volatile Organic Compound (VOC)**†	
Integrated Temperature/RH	ZW-003	0-10, 0-100, 0-1000 ppm	T-ION-TVOC
External- T/RH, (1) analog, (1) pulse	ZW-005	Temperature Sensors	
External- (4) analog	ZW-006	Air/Water/Soil Probe 0.3m (1ft)	TMC1-HD
External- T/RH, (2) analog	ZW-007	Air/Water/Soil Probe 1.8m (6ft)	TMC6-HD
External- (2) analog, (2) pulse	ZW-008	Air/Water/Soil Probe 6.1m (20ft)	TMC20-HD
kWh***		Air/Water/Soil Probe 15.2m (50ft)	TMC50-HD
WattNode Wye config 208/240	T-WNB-3Y-208	Stainless Steel Temp Probe 1.8m (6ft)	TMC6-HC
WattNode Wye 208/240 opt P3	T-WNB-3Y-208P	Pipe Temp 1.8m (6ft)	TMC6-HE
WattNode Delta/Wye config 208/240	T-WNB-3D-240	Split-core AC Current Sensors	
WattNode Delta/Wye config 480	T-WNB-3D-480	0-20 Amps AC	CTV-A
"B" Series Voltage Lead Set	A-WNB-LEADSET	0-50 Amps AC	CTV-B
Veris 1-phase, 300 Amp	T-VER-8051-300	0-100 Amps AC	CTV-C
Veris 3-phase, 800 Amp	T-VER-8053-800	0-200 Amps AC	CTV-D
Water Flow***		0-600 Amps AC	CTV-E
Water Flow Meter	T-MINOL-130	CO <sub>2</sub> **	
kW**		Telaire CO <sub>2</sub> /Temp Monitor	TEL-7001
3 Phase, 480V, 100 AMP	T-VER-8044-100	AC Voltage Transmitters**	122 7001
Gauge Pressure**†		0 - 150 Volts AC	T-CON-ACT-150
100 psig	T-ASH-G2-100	0 - 300 Volts AC	T-CON-ACT-130
200 psig	T-ASH-G2-200	DC Voltage	1 CON ACT 500
500 psig	T-ASH-G2-500	0 - 2.5 Volts DC	CABLE-2.5-STEREO
<b>Differential Air Pressure Transduce</b>	-**†	0 - 5 Volts DC	CABLE-ADAP5
.01-10.0 WC	T-VER-PXU-L	0 - 10 Volts DC	CABLE-ADAP10
.01-10.0 WC	T-VER-PXU-X		CADLL-ADAF 10
Humidity**†		Milliamps	CARLE 4 20MA
Duct-Mount RH/Temp	T-VAI-HMD-40Y	4 - 20mA <b>Software</b>	CABLE-4-20MA
DC Current**†		HOBOware Pro Software	
0-200 Amp	T-VER-H970-200	(Windows®/MAC®)	
-200 to 200 Amp	T-VER-971BP-200	Accessories	
Air Velocity Sensor**†		Sensor Power Adapter,	
0.15-10 m/s	T-DCI-F900-L-P	12 Volt DC @ 400mA	AC-SENS-1
0.15-5 m/s	T-DCI-F900-L-O		
0.15-10 m/s	T-DCI-F900-S-P		
0.15-5 m/s	T-DCI-F900-S-O		
* Requires HOBOware Pro software ** Requires input cable *** Requires pulse input adapter			

- \*\*\* Requires pulse input adapter
- † Requires sensor power adapter (AC-SENS-1)

Power adapters are supplied with ZW-RCVR, ZW-ROUTER, and all data node models.



### Sensor Compatibility Chart

Measurement	Part Number	Adapter Cable	Excitation Required	Power Source
DC Amperage -200 to 200 AMP	T-VER-971BP-200	CABLE-4-20mA	12 VDC, 35mA	AC-SENS-1
DC Amperage 0 - 200 AMP	T-VER-H970-200	*CABLE-ADAP5		AC-SENS-1
AC Voltage Transmitters up to 300 VAC	T-CON-ACT-xxx	CABLE-4-20mA		
Split-Core AC Current Sensors up to 600 AMP	CTV-x	-		
Power (kW) 3 phase, 100 AMP	T-VER-8044-100	CABLE-4-20mA	12Vdc, 30mA	AC-SENS-1
Kilowatt Hours (kWh) 1 phase, 300 AMP	T-VER-8051-300	CABLE-2.5-STEREO		
Kilowatt Hours (kWh) 3 phase, 800 AMP	T-VER-8053-800	CABLE-2.5-STEREO		
Kilowatt Hours (kWh) Delta/Wye 240	T-WNB-3D-240	CABLE-2.5-STEREO		
Kilowatt Hours (kWh) Delta/Wye 480	T-WNB-3D-480	CABLE-2.5-STEREO		
Kilowatt Hours (kWh) Wye 208/240	T-WNB-3Y-208	CABLE-2.5-STEREO		
Gauge Pressure	T-ASH-G2-xxx	CABLE-ADAP5	12 VDC, 5mA	AC-SENS-1
Differential Air Pressure	T-VER-PXU-L	*CABLE-ADAP10	12Vdc, 35mW	AC-SENS-1
Differential Air Pressure	T-VER-PXU-X	*CABLE-ADAP10	12Vdc, 35mW	AC-SENS-1
Carbon Dioxide	TEL-7001	CABLE-C0 <sub>2</sub>		comes with AC adapter
Compressed Air Flow Meter	T-CDI-5200-10S	*CABLE-2.5-STEREO	comes with AC adapter	comes with AC adapter
Compressed Air Flow Meter	T-CDI-5400-20S	*CABLE-2.5-STEREO	comes with AC adapter	comes with AC adapter
Water Flow Meter	T-MINOL-130	CABLE-2.5-STEREO		
Air Velocity	T-DCI-F900-L-x	CABLE-ADAP5	12Vdc, 70mA	AC-SENS-1
Air Velocity	T-DCI-F900-S-x	CABLE-ADAP5	12Vdc, 70mA	AC-SENS-1
Volatile Organic Compound (VOC)	T-ION-TVOC	CABLE-4-20mA	12Ddc, 300mA	AC-SENS-1
Stainless Steel temp Probe	TMC6-HC	-		
Pipe Temperature	TMC6-HE	-		
Air Water Soil Temperature	TMCx-HD	-		
0 - 10vdc Input Sensor	CABLE-ADAP10	-		
0 - 5vdc Input Sensor	CABLE-ADAP5	-		
0 - 2.5 Vdc or Pulse Input Sensor	CABLE-2.5-STEREO	-		
4-20mA Input Sensor	CABLE-4-20MA	-		

<sup>\*4-20</sup>mA output option requires CABLE-4-20mA

#### **Contact Us**

- Speak with an application specialist by calling FH€ÂÎÎÂÎÏ
- Email your inquiry to sales@onet^{ ] .com.au

## **About OneTemp**

We take pride in providing the best fit for your needs with our range of quality instrumentation products that have been carefully selected from amongst the worlds best. We offer an extensive choice in measuring, controlling and recording instruments for industrial and research applications in Australia with over 35 years of experience to speak for us.

Through the years, we have built an enviable foundation in being a solution focused company with a strong commitment to service excellence. Our quality assurance is backed by a highly trained after sales care team in each office and the OneTemp Service and Calibration Centre.

Copyright © 2010 Onset Computer Corporation. All rights reserved. Onset, HOBO and HOBOware are registered trademarks of Onset Computer Corporation. Other products and brand names may be trademarks or registered trademarks of their respective owners.